

myReader User Guide Addendum

▶ PC Compatibility

The set of compatible video modes now includes:

- 640 x 480 at 60 or 75 Hertz
- 800 x 600 at 60 or 75 Hertz
- 1024 x 768 at 60 or 75 Hertz

If you change your PC's video mode, allow at least five seconds for myReader to detect and adapt to the new mode. While this is happening, myReader will display the message "Auto detection" and when synchronized will automatically go back to the previous full screen or split-screen setting.

If the new video mode is not compatible with myReader, the message "Incompatible mode" will be displayed along with information about the video mode.

If the PC is switched off or disconnected, the message "No signal" will be displayed.

The split-screen display settings can be adjusted in the menu as described below.

When displaying the full screen PC picture, the myReader's lights are not needed and can be automatically switched off after a time delay. The time delay can be set in the menu as described below.

▶ **Split Screen Menu (Within the Advanced Menu)**

▪ **Ratio**

Set the ratio between the PC part of the display and the myReader camera part of the display. The default is 50%/50%.

▪ **PC Display**

Specify which part of the display the PC picture is displayed on. The options are Top or Bottom (with a horizontal split) or Left or Right (with a vertical split). The default is Top.

▪ **Lights Off**

Set the time delay after the full screen PC display or external camera display is selected before the myReader's lights go off. The default is 2 minutes. "On" can be selected to disable this feature.

▶ **Stopping Automatic Scrolling**

Pressing the NEXT button will now stop the text scrolling if it is automatically scrolling

▶ **Live Mode Position**

The viewing area in Live Mode is now at the front of the platter.